

The BioLab mixer - improve your safety



The BioLab mixer is a user-friendly one-handle mixer with an improved design. According to the EN12128 standard, mixers in laboratories must be hands-free. The BioLab mixer can be operated using the wrist or elbow.



Reduces risks

The handle is placed in front of the water outlet to minimize the risk of damaging the eyes, as the eye shower is usually placed next to the water outlet.



Focus on safety

The BioLab mixer is colour-coded based on EN13792 to highlight which media is provided by the mixer.



Easy access

The handle follows the water outlet to ensure the optimum user-friendliness.

Safety is handled

The one-handle mixer



The one-handle mixer was supplied with a long handle to ensure hands-free operation. The long handle ensured that the mixer could be operated using wrist or forearm.

The length of the handle, however, increases the risk of hurting an eye on the handle while using the eye shower. Even when turning the water outlet to the left, the handle might get in front of the eye shower.

BioLab mixer



The handle is shortened but is very user-friendly.

The risk of damaging the eyes when an eye shower is placed next to the mixer is minimized.

As the handle follows the water outlet, high glassware can easily be rinsed. The colour-coded handle highlights which media is supplied by the mixer.

All the great features

- Standard mounting kits
- Swivel limitation
- Changeable hoses
- Aerator, hose nozzle and FlowFix